




GUIDE D'UTILISATION SK-1000



Bouton 1 -A/ Presser pour armer.
-B/ Presser 2 secondes pour « panique »
(Presser à nouveau pour arrêter).
-C/ Presser lorsque le système est armé pour localiser
le véhicule.

Bouton 2 -A/ Presser pour désarmer.
-B/ Presser 2 secondes lorsque le moteur est en marche
pour mettre ou enlever le mode valet.

Bouton 1 et 2 simultanément -/ Ouverture du coffre arrière (option)

Bouton 3 -/ Utilisation future

Pour désarmer le système par l'interrupteur:

Ignition à « on ».

Appuyer une fois sur l'interrupteur.

Attendre au moins 3 secondes.

Le système est maintenant désarmé.

OPTIONS: Cocher si l'option est installée

Verrouillage / déverrouillage des portières


Ouverture de valise télécommandée

Alarme / klaxon





SK-1000 USER GUIDE



Button 1 -A/ Press to arm.
-B/ Press 2 seconds for « panic »
(press again to stop).
-C/ Press when system is armed to locate the vehicle.

Button 2 -A/ Press to disarm.
-B/ Press 2 seconds when the engine is running to
to enter or remove valet mode.

Button 1 and 2 simultaneously / Trunk release optional.

Button 3 / For future use.

To disarm the system by the switch:

Ignition at « on ».
Press switch once.
Wait at least 3 seconds.
The system is now disarmed.

OPTIONS: Indicate if installed.

Door lock / unlock
Remote trunk release
Alarm

